



FAQ - How do I connect an additional local Sky digital box in a Connected Room?

how to wire




If you want a local **Skydigibox** in a Connected Room you can watch whatever channels you wish. The Satellite receiver is connected to the Room Media Socket. You will need to connect the 'spare' Sat 2 return feed of the Room Media Socket for the Connected Room (the white WM100 coax cable) to a spare feed from the satellite dish. This will require come connection work at the **DP**.

connection diagram



- 1 Connect the White WM100 return feed from the Room Media Socket to a feed from the Satellite Dish* using an F-Barrel



* you may need a multiple-output LNB - please call if you need advise

- 2 Connect the 'SAT2' on the Room Media Socket to the 'DISH INPUT' on the Sky digi box.
- 3 Connect the 'TV' on the Room Media Socket to the 'AERIAL IN' on the Sky digi box.
- 4 Connect the 'RF-OUT 1' on the Sky digi box to the 'RF-IF' on the VCR / DVD Recorder. Connect the 'RF-OUT ' on the VCR / DVD Recorder to the 'UHF' aerial in on your TV.
- 5 Connect the VCR / DVD Recorder to the Sky digi box using a Scart lead.
- 6 Connect the TV to the Sky digi box using a Scart lead.
- 7 Connect the TV to the VCR / DVD Recorder with a Scart lead.
- 8 Connect the Sky digi box to a telephone socket. If you also need to use a phone at this location, please refer to our FAQ sheets.



Note: If you do not have a VCR/DVD recorder some of these connections may not be necessary.