



To set bass, treble, and volume levels

1. Turn zone on



Blue

2. Select set-up mode




Hold
down together




Blue Green

3. Adjust turn-on volume*



4. Step to next parameter




Green flash three times

5. Adjust bass*




6. Step to next parameter




Green flash twice

7. Adjust treble*




8. Step to next parameter




Green flash twice

9. Adjust maximum volume*



10. Exit from set up



Green flash three times

11. Speaker ready for use



Red
Standby

*If a parameter does not need to be changed, press  to skip to next parameter.